Class 2 Dual Level Sound Calibrator



Features

- IEC 60942:2003 Class 2
- ANSI S1.40:2006
- Dual level 94 and 114 dB
- Frequency 1 kHz
- Fits ½" microphones
- Adapter available for ¼" microphones

Applications

- Calibration check of Class 2 sound level meter
- Calibration check of noise dosimeters
- One calibrator for multiple meters
- Field calibration checks

Overview

The CR516 Acoustic Calibrator meets ANSI S1.40:2006 and IEC 60942:2003 to Class 2. It is designed for use with the Class 2 sound level meters and noise dosimeters that NoiseMeters offers.

Hand held sound level meters generally expect a calibration level of 94 dB at a frequency of 1 kHz. Noise dosimeters, which mount on a worker's shoulder to monitor daily noise exposure levels, often expect a calibration level of 114 dB at 1 kHz. Rather than having two calibrators the CR516 can be switched on at either 94 dB or 114 dB for use with either noise measurement device.

Using It

When the Calibrator is switched on it emits a 1 kHz tone at either 94 dB or 114 dB. The calibrator should be pushed carefully (firmly, but slowly) on to the microphone capsule of the sound level meter or noise dosimeter.

The meter should now be adjusted accordingly. Older sound level meters will have to be adjusted manually to the correct reading. Most modern meters (and all those supplied by NoiseMeters) adjust themselves automatically.

NoiseMeters

Class 2 Dual Level Sound Calibrator

Specifications

Standards IEC 60942:2017 Class 2

ANSI S1.40:2006

Sound Level $94.0 \text{ dB} \pm 0.4 \text{ dB}$

 $114.0 \text{ dB} \pm 0.4 \text{ dB}$

Frequency 1 kHz \pm 1%

Distortion < 2%

Reference 23°C, 101.3 kPa, 65% RH

conditions

Microphone ½" (to IEC 1094-4)

size

Calibration QD7 for use with 1/4" adapter microphone capsules Battery type 1 x 9v (PP3, 6LR61, 6F22)

Dimensions 121 x Ø47 mm Weight 220 g with battery

Controls Push button start at 94dB,

push again for 114dB

LED power indicator. Manual

or auto switch off

CE EN 61000-6-3:2007+A1:2011

classification

EN 61000-6-1:2007

Head Office

NoiseMeters Ltd 7 Jayes Park Ockley Surrey RH5 5RR

Telephone **+44 130 677 0855** Fax **+44 845 680 0316**

Email: info@noisemeters.ie Support: support@noisemeters.ie

Web Sites

Main site:

https://www.noisemeters.ie

Product shortcut:

https://www.noisemeters.ie/p/cr516/

Tech Support:

https://support.noisemeters.com